



Renaissance Series

2020 Critical Care Bed OPERATIONS MANUAL

**For Parts or Technical Assistance
1-800-327-0770**

Table of Contents

Introduction	2
Specifications	2
Warning / Caution / Note Definition	2
Set-up Procedures	3
Operation Guide	
Operating Symbols	4
Led Display	5
Function Lockout/Scale System On/Off/Reset	5
Cardiac Chair	5
Emergency Drop	5
Emergency Stop	5
Operating Directional Steering Caster	6
Operating Optional Oxygen Bottle Holder	6
Using the 110 Volt Outlet Option	6
Operating Optional Permanently Attached I.V. Pole	7
Using the Equipment Tray Options	7
Using the Optional X-Ray Cassette Holder	8
Control Panel Guide	9
Weigh System Usage	10,11
Weigh System Control Panel Guide	12,13
Patient Control/Nurse Control Guide	14
Integrated Dynamic Mattress System Operation	15
Limited Warranty	
Obtaining Parts and Service	16
Supplemental Warranty Coverage	16
Return Authorization	17
Freight Damage Claims	17

Introduction

INTRODUCTION

This manual is designed to assist you with the operation of the 2020 Renaissance Series Critical Care Bed. Read it thoroughly before using the equipment.

SPECIFICATIONS

Maximum Weight Capacity	500 pounds
Overall Bed Length/Width	90"/38"
Minimum/Maximum Bed Height	22.5"/35"
Knee Gatch Angle	0 degrees to 35 degrees
Fowler Angle	0 to 90 Degrees
Trendelenberg/Reverse Trendelenberg	-12 degrees to +12 degrees
Weigh System Accuracy (optional equipment)	+ / - 1% of total patient weight
Electrical Requirements	110 VAC, 60 Hz, 5.0 Amp

WARNING / CAUTION / NOTE DEFINITION

The words WARNING, CAUTION and NOTE carry special meanings and should be carefully reviewed.

WARNING

The personal safety of the patient or user may be involved. Disregarding this information could result in injury to the patient or user.

CAUTION

These instructions point out special procedures or precautions that must be followed to avoid damaging the equipment.

NOTE

This provides special information to make maintenance easier or important instructions clearer.

SET-UP PROCEDURES

It is important that the 2020 Renaissance Series Critical Care Bed is working properly before it is put into service. The following list will help assure that each part of the bed is tested.

- Depress the curved pedal at either end of the bed fully to set the four wheel brakes and assure all four casters lock. Lift the pedal to the neutral position to release the brakes.
- Lift the pedal and assure the steering caster locks at the foot end of the bed (on the patient's right side only). Depress the pedal fully to set the brakes.
- Assure the bed will lower to the full down position by depressing both pedals at the foot end of the bed.
- Raise the bed to the full up position by pumping the pedal identified by the "bed up" label on the base hood. Assure the head end lowers to the full down position by depressing the pedal identified by the Trendelenberg (head down) label.
- Depress the pedal identified by the Reverse Trendelenberg (foot down) label and assure the foot end lowers to the full down position.
- Raise the bed to the full up position. Pivot the manual override Fowler crank up into position. Push in the crank and hold it in while turning it clockwise to raise the Fowler. Assure it will raise to at least 90 degrees. Hold the crank in and turn it counterclockwise to lower the Fowler. Assure it will lower to flat.
- Pivot the manual override Knee Gatch crank up into position. Push in the crank and hold it in while turning it clockwise to raise the Knee Gatch. Assure it will raise to 35 degrees. Hold the crank in and turn it counterclockwise to lower the Knee Gatch. Assure it will lower to flat.
- Assure the siderails raise and lower smoothly and lock in the up and intermediate positions.
- Plug the bed into a properly grounded, hospital grade wall receptacle. Assure the "BED ON" light on the foot end keypad comes on.


WARNING

The 2020 is equipped with a hospital grade plug for protection against shock hazard. It must be plugged directly into a properly grounded three-prong receptacle. Grounding reliability can be achieved only when a hospital grade receptacle is used.

- Push the scale system On/Off/Reset switch (under the foot end frame end, next to the function lock-out switches) away from you to turn on the weigh system (see page 5 for diagram).
- Run through each function on the head end and foot end control panels and assure that each is working properly (see control panel guide page 9 and weigh system control panel guide page 12 & 13).
- Assure all functions are working properly on the patient controls or the in-rail nurse controls, if the bed is equipped with them.


Operation Guide

OPERATING SYMBOLS




Fowler Crank

To raise the Fowler, push in the crank and hold it in while turning it clockwise.
To lower the Fowler, push in the crank and hold it in while turning it counter-clockwise.




Knee Gatch Crank

To raise the Knee Gatch, push in the crank and hold it in while turning it clockwise.
To lower the Knee Gatch, push in the crank and hold it in while turning it counterclockwise.



Lift Pedal


Pump pedal to raise bed.



Trendelenberg Pedal

Depress pedal to lower head end.


Note: Depress both Trendelenberg pedals at the same time to lower litter.



Reverse Trendelenberg Pedal

Depress pedal to lower foot end.

Note: Depress both Trendelenberg pedals at the same time to lower litter.



Brake/Steer Pedal

Depress pedal fully to set four wheel brakes.
Lift pedal fully to engage steer caster.

LED DISPLAY

There is an optional LED display to show the angle of the Fowler and the angle of Trendelenberg/Reverse Trendelenberg. The Fowler display lights will change as the Fowler is moved electrically by pressing the control panel button or manually by cranking. The bed must be plugged into a wall socket for the display lights to work. The Fowler display is for 15 degree increments only. The Trendelenberg display lights will change whenever the angle of Trendelenberg/Reverse Trendelenberg is changed electrically by pressing the control panel button or manually by depressing the pedals. Again, the bed must be plugged in for the lights to work. The Trendelenberg display is for 4 degree increments only.

FUNCTION LOCKOUT/SCALE SYSTEM ON/OFF/RESET

Under the foot end keypad, there are seven lockout switches. These switches are identified with symbols (see below). Pull the switch toward you to individually lock out bed up/down, Fowler, Knee Gatch, Trendelenberg/Reverse Trendelenberg, cardiac chair (optional) and the patient controls (optional). If the keypad button is pressed for a function that is locked out, a horn will sound and the bed will not respond. The seventh switch at the far right of the group is the scale system on/off/reset switch. It is used to reset the scale system if an unusual symbol or character is displayed on the scale monitor or if the scale system operates in any other erratic manner. It will not clear the bed zero information stored in the scale system memory.



CARDIAC CHAIR

To activate the optional Cardiac Chair function, press and hold the button on the foot end control panel. The Knee Gatch will raise, the Fowler will raise or lower to 51 degrees and the bed will tilt to –12 degrees Reverse Trendelenberg. Release the button to stop bed movement: hold the button until movement stops to complete the function.

EMERGENCY DROP

To activate the optional Emergency Drop function, press and hold the "ON" button on the foot end control panel for two seconds. The bed will level from Trendelenberg/Reverse Trendelenberg, the Fowler will lower to flat, the Knee Gatch will lower to flat and the litter will lower to full down. Press the "OFF" button when the function is complete.

NOTE

Both the Cardiac Chair and the Emergency Drop functions are stopped by safety switches if there is an obstruction under the Fowler or Knee Gatch. To start Cardiac Chair after clearing the obstruction, press the function button again. To start Emergency Drop after clearing the obstruction, press the start button again.


EMERGENCY STOP

Pressing the Emergency Stop button on the head end control panel will interrupt any downward motion. Emergency Stop overrides both control panels and the patient or in-rail nurse controls.

Operation Guide

OPERATING DIRECTIONAL STEERING CASTER

When transporting a patient, the steer caster helps to maintain the bed's path along a straight line and aids pivoting at corners.




Brake/Steer Pedal

Depress pedal fully to set four wheel brakes.

Lift pedal fully to engage steer caster.

For proper "tracking" of the steer caster, push the bed approximately 10 feet to allow the wheels to face the direction of travel before engaging the steer pedal. Without doing this, proper "tracking" will not occur and it will be difficult to steer the bed.

OPERATING OPTIONAL OXYGEN BOTTLE HOLDER



1. To use oxygen bottle holder, rotate (A) upward until it stops in an upright position, as shown.
2. To store, when not in use, rotate (A) downward until it stops (flat position).

USING THE 110 VOLT OUTLET OPTION

CAUTION

Only use equipment with the following electrical specifications: 125 VAC; 5A; 60Hz.

Maximum total load drawn by equipment used in this receptacle outlet must not exceed 10A.


The bed power cord must be plugged into a properly grounded three prong wall receptacle for the bed outlet to work.

If the equipment plugged into the bed outlet is not receiving power, change the fuse located on the base assembly at the head end of the bed, near the serial number label.

CAUTION

To avoid risk of fire, replace fuse with a 3AB type, 250V, 10A Slow Blo fuse.

OPERATING OPTIONAL PERMANENTLY ATTACHED I.V. POLE



NOTE

An optional permanently attached I.V. Pole may have been installed at either the head, foot or both ends of the stretcher. The choice was made at the time the stretcher was purchased.

To Use the I.V. Pole:

1. Lift the I.V. pole from the I.V. rest and hinge downward into receptacle (A).
2. To increase the height of the pole, turn the lock actuator (B) counterclockwise and pull up on the telescoping portion (C). Raise the pole to the desired height.
3. Turn the lock actuator (B) clockwise to lock the telescoping portion in place.

CAUTION

The weight of the I.V. bags should not exceed 40 pounds.

USING THE EQUIPMENT TRAY OPTIONS


CAUTION

Both the equipment (defibrillator) tray and the equipment tray/footboard combination options have a 40 lb. limit.

To use the equipment tray/footboard combination option, mount as shown in the illustration. The tray can be pivoted out of the way when not in use by pulling knob (A) and rotating tray to stored position.


NOTE

The equipment (defibrillator) tray and the equipment tray/footboard combination are interchangeable between beds.



Operation Guide

USING THE OPTIONAL X-RAY CASSETTE HOLDER




1. To access the Fowler x-ray cassette holder, raise the Fowler section.
2. Grasp handles (A) and squeeze, allowing locating pins (B) to disengage from mounting brackets (C).
3. Lower tray and install x-ray cassette.
4. Reverse steps 1 & 2 to engage loaded tray to Fowler mounting brackets (C).

NOTE


The tray position can be adjusted, from the patient's head to the buttocks area, by loosening knob (D), sliding the tray to the desired position, and re-tightening (D) to hold the position.

SYMBOL

BED ACTION



Litter will raise.



Litter will lower.



Fowler will raise.




Fowler will lower.*




Knee Gatch will raise.



Knee Gatch will lower.*



Head end tilts down.**




Foot end tilts down.**

*There are individual safety switches to stop the movement of the Fowler and Knee Gatch if there is an obstruction under either one. The obstruction must be cleared before the function will continue.

**If the litter is at its lower limit when the Trendelenberg button is pressed, the foot end of the bed will raise to achieve the desired angle for the bed. If the Reverse Trendelenberg button is pressed when the bed is at its lower limit, the head end of the bed will raise to achieve the desired angle.

Weigh System Usage



BEFORE PUTTING A NEW PATIENT ON THE BED

- There is a scale system on/off/reset switch under the frame end at the foot end of the bed along with the function lockout switches. It is used to reset the scale system if an unusual symbol or character is displayed on the scale monitor or if the scale system operates in any other erratic manner. It will not clear the bed zero information stored in the scale system memory,
- Press and release "PATIENT WEIGHT SYSTEM ON". The scale monitor will read:
"WEIGHING"
"XXX.X LB GXX.X"
- Press and release "LOCK/UNLOCK". The scale monitor will read:
"LOCK/UNLOCK KEY?"
- Press and hold "ZERO BED". The scale monitor will read:
"KEY NOW UNLOCKED"
"HOLD TO ZERO WT."
"RELEASE TO ZERO"
- Release "ZERO BED". The scale monitor will now read:
"DO NOT TOUCH BED"
"0.0 LB"

AFTER PUTTING A NEW PATIENT ON THE BED

- Press and release "PATIENT WEIGHT SYSTEM ON". After the scale monitor reads "XXX.X LB", press and hold "ZERO GAIN/LOSS". The scale monitor will read:
"HOLD TO ZERO G/L"
"RELEASE TO ZERO"
- Release "ZERO GAIN/LOSS". The scale monitor will read:
"DO NOT TOUCH BED"
"XXX.X LB G00.0"

NOTE

If a negative sign (-) appears in the patient weight display, weight has been removed from the bed after the "ZERO BED" function was completed. "ZERO BED" must be completed again before patient weight readings will be accurate.

AFTER PUTTING A NEW PATIENT ON THE BED (CONTINUED)

- If it is necessary to add or remove special equipment (monitors, pumps, etc.) during the patient's stay, press and release "PATIENT WEIGHT SYSTEM ON" to activate the weigh system. After the scale monitor reads "XXX.X LB GXX.X", press and hold "CHANGE EQUIP." The scale monitor will read:

"HOLD TO START"

"RELEASE TO START"

- Release "CHANGE EQUIP." The scale monitor will read:

"DO NOT TOUCH BED"

"ADD/REMOVE EQUIP"

- Add or remove the equipment and press "CHANGE EQUIP. END". The scale monitor will read:

"RELEASE TO FIN."

- Release "CHANGE EQUIP. END". The scale monitor will read:

"DO NOT TOUCH BED"

"XXX.X LB GXX.X"

NOTE

Do not remove the patient from the bed before completing the equipment change function or the patient's weight will stay in the memory and be added to the next patient's weight reading. To remove the previous weight reading from the memory, remove the patient from the bed and complete the "ZERO BED" function again.

- To convert the patient's weight and weight gain/loss to kilograms, press and release "PATIENT WEIGHT SYSTEM ON" to activate the weigh system. After the scale monitor reads "XXX.X LB GXX.X", press and release the "LBS/KGS" button. The scale monitor will read:

"WEIGHT NOW KGS"

"XXX.X KG GXX.X"

- Repeat the procedure to return to pounds. The display will read:

"WEIGHT NOW LBS"

"XXX.X LB GXX.X"





- The display will turn off approximately one minute after a function is completed. The patient's weight and weight gain/loss will still be in the weigh system memory and will be displayed whenever the "PATIENT WEIGHT SYSTEM ON" button is pressed.

NOTE





If the "EQUIPMENT CHANGE" function is started but not completed, the display will not turn off and will continue to read:

"ADD/REMOVE EQUIP"

Weigh System Control Panel Guide

SYMBOL	ACTION	DISPLAY
	To prepare bed for new patient:	
	Press and release "PATIENT WEIGHT SYSTEM ON" to activate the scale system, begin a new function and to display patient weight.	"WEIGHING..." "XXX.X LB GXX.X"
	Press and release "LOCK/UNLOCK" to begin the "ZERO BED" function.	"LOCK/UNLOCK KEY?"
	Press and hold "ZERO BED".	"KEY NOW UNLOCKED" "HOLD TO ZERO WT." "RELEASE TO ZERO"
	Release "ZERO BED"	"DO NOT TOUCH BED" "0.0 LB"
	After putting new patient on bed:	
	Press and release "PATIENT WEIGHT SYSTEM ON" Press and hold "ZERO GAIN/LOSS"	"XXX.X LB" "HOLD TO ZERO G/L" "RELEASE TO ZERO"
	Release "ZERO GAIN/LOSS"	"XXX.X LB G00.0"

Weigh System Control Panel Guide

SYMBOL	ACTION	DISPLAY
	To add or remove equipment during patient stay without affecting registered patient weight: Press "PATIENT WEIGHT SYSTEM ON"	"XXX.X LB GXX.X"
	Press "CHANGE EQUIP. START" Release "CHANGE EQUIP START" Add or remove equipment.	"HOLD TO START" "RELEASE TO START" "DO NOT TOUCH BED" "ADD/REMOVE EQUIP"
	Press "CHANGE EQUIP. FINISH" Release "CHANGE EQUIP. FINISH"	"RELEASE TO FIN." "DO NOT TOUCH BED" "XXX.X LB GXX.X"
	To lockout any weigh system function except "PATIENT WEIGHT SYSTEM ON" and "LOCK/UNLOCK":	
	Press and release "LOCK/UNLOCK" Press and release selected weigh system button. Multiple functions can be locked out by repeating the above step. If a button is pressed for a function that has been locked out, the display will read: To unlock a function: Press and release "LOCK/UNLOCK" Press and release selected button	"LOCK/UNLOCK KEY?" "KEY NOW LOCKED" "KEY LOCKED OUT" "LOCK/UNLOCK KEY?" "KEY NOW UNLOCKED"
	To convert the patient's weight to kilograms, press and release "LBS/KGS" Repeat the procedure to return to pounds.	"WEIGHT NOW KGS" "XXX.X KG GXX.X"

Patient Control/Nurse Control Guide

SYMBOL

ACTION



Fowler will raise.




Fowler will lower.



Knee Gatch will raise.




Knee Gatch will lower.




Litter will raise.



Litter will lower.



Head end will lower/foot end will raise.



Foot end will lower/head end will raise.

Integrated Dynamic Mattress System Operation

OPERATING OPTIONAL INTEGRATED DYNAMIC MATTRESS SYSTEM

NOTE

The Integrated Dynamic Mattress System will be active whenever the bed is plugged into the wall socket.

DMS MATTRESS CONTROL
AUTO / MANUAL LOCKOUT SWITCH 

*When the lockout switch on the foot end frame end is not activated, the Dynamic Mattress System can be operated in either the AUTOMATIC or the MANUAL mode. When in the AUTOMATIC mode, the internal air bladder will be inflated to a preselected pressure and the FIRM and SOFT buttons on the siderail control are disabled. The system must be in MANUAL mode for the firmness of the mattress to be adjusted. To lockout the mode that is not active, pull the lockout switch toward the foot end of the bed. This disables the AUTO/MANUAL button on the siderail control and keeps the DMS operating in the mode currently active.

Dynamic Mattress Siderail Control



Press to change from automatic to manual operation mode or back.*



Press to make the mattress firmer (when in manual mode).



Press to make the mattress softer (when in manual mode).



LED indicates mattress is operating in AUTOMATIC mode.



LED indicates mattress is operating in MANUAL mode. Will blink when either the FIRM or SOFT button is pressed to indicate the system is operating properly.



LED indicates possible air loss in mattress system.

Warranty

Limited Warranty:

Stryker Medical Division, a division of Stryker Corporation, warrants to the original purchaser that its products should be free from defects in material and workmanship for a period of one (1) year after date of delivery. Stryker's obligation under this warranty is expressly limited to supplying replacement parts and labor for, or replacing, at its option, any product which is, in the sole discretion of Stryker, found to be defective. Stryker warrants to the original purchaser that the frame and welds on its beds will be free from structural defects for as long as the original purchaser owns the bed. If requested by Stryker, products or parts for which a warranty claim is made shall be returned prepaid to Stryker's factory. Any improper use or any alteration or repair by others in such manner as in Stryker's judgement affects the product materially and adversely shall void this warranty. No employee or representative of Stryker is authorized to change this warranty in any way.

This statement constitutes Stryker's entire warranty with respect to the aforesaid equipment. STRYKER MAKES NO OTHER WARRANTY OR REPRESENTATION, EITHER EXPRESSED OR IMPLIED, EXCEPT AS SET FORTH HEREIN. THERE IS NO WARRANTY OF MERCHANTABILITY AND THERE ARE NO WARRANTIES OF FITNESS FOR ANY PARTICULAR PURPOSE. IN NO EVENT SHALL STRYKER BE LIABLE HEREUNDER FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM OR IN ANY MANNER RELATED TO SALES OR USE OF ANY SUCH EQUIPMENT.

To Obtain Parts and Service:

Stryker products are supported by a nationwide network of dedicated Stryker Field Service Representatives. These representatives are factory trained, available locally, and carry a substantial spare parts inventory to minimize repair time. Simply call your local representative, or call Stryker Customer Service at (800) 327-0770.

Supplemental Warranty Coverage:

Stryker has developed a comprehensive program of extended warranty options designed to keep your equipment operating at peak performance at the same time it eliminates unexpected costs. We recommend that these programs be activated *before* the expiration of the new product warranty to eliminate the potential of additional equipment upgrade charges. Stryker offers the following Supplemental Warranties:

Extended (Parts and Labor)

- All replacement parts (excluding mattresses and consumable items)
- Labor and travel for *all* scheduled and unscheduled calls
- Biannual Preventive Maintenance Inspections and repairs
- JCAHO paperwork for preventive maintenance
- Priority Emergency Service

Standard (Labor Only):

- Labor and travel for *all* scheduled and unscheduled calls
- Biannual Preventive Maintenance Inspections and repairs
- JCAHO paperwork for preventive maintenance
- Priority Emergency Service

Basic (Parts Only):

- All replacement parts (excluding mattresses and consumable items)
- Priority Emergency Service

Please call your local representative, or call (800) 327-0770 for further information

Return Authorization:

Merchandise cannot be returned without approval from the Stryker Customer Service Department. An authorization number will be provided which must be printed on the returned merchandise. Stryker reserves the right to charge shipping and restocking fees on returned items.

SPECIAL, MODIFIED, OR DISCONTINUED ITEMS NOT SUBJECT TO RETURN.

Damaged Merchandise:

ICC Regulations require that claims for damaged merchandise must be made with the carrier within fifteen (15) days of receipt of merchandise. **DO NOT ACCEPT DAMAGED SHIPMENTS UNLESS SUCH DAMAGE IS NOTED ON THE DELIVERY RECEIPT AT THE TIME OF RECEIPT.** Upon prompt notification, Stryker will file a freight claim with the appropriate carrier for damages incurred. Claim will be limited in amount to the actual replacement cost. In the event that this information is not received by Stryker within the fifteen (15) day period following the delivery of the merchandise, or the damage was not noted on the delivery receipt at the time of receipt, the customer will be responsible for payment of the original invoice in full.

Claims for any short shipment must be made within thirty (30) days of invoice.

International Warranty Clause:

This warranty reflects U.S. domestic policy. Warranty outside the U.S. may vary by country. Please contact your local Stryker Medical representative for additional information.



6300 Sprinkle Road, Kalamazoo, MI 49001-9799

(800) 327-0770

DH 11/93 2020-1-126 REV D